



1999-2003
Ford F150 - 250 Light Duty -Expedition (99-02)
40931 / 40932 / 40933
Installation Instructions

Hardware Included
2- 1/4-20 x 3/4" bolts
2- 1/4-20 lock nuts

- 1- Center billet grille in bumper opening and mark hole location on vertical bars.
- 2- Drill 1/4" hole in vertical bar. Install billet grille with enclosed hardware.



1999-2003
Ford F150 - 250 Light Duty -Expedition (99-02)
40931 / 40932 / 40933
Installation Instructions

Hardware Included
2- 1/4-20 x 3/4" bolts
2- 1/4-20 lock nuts

- 1- Center billet grille in bumper opening and mark hole location on vertical bars.
- 2- Drill 1/4" hole in vertical bar. Install billet grille with enclosed hardware.