



**41061 / 41062 / 41063      Installation Instructions 1969 Chevy Camaro**

1. Remove the stock grille shell.
  - Optional: Removing the four bolts that hold on the front bumper makes the install much easier.
2. Remove the center section of the stock grille between the headlights, leaving the small chrome strip. Sand this area smooth if needed.
3. Place the billet grille's front edge flush with the backside of the chrome strip on the stock grille.
4. With the billet grille in place mark the center location of each vertical rod in preparation of drilling a 1/8" hole at these locations.
5. Using the supplied hardware (pop rivets or self tapping screws) secure the billet grille in place.
6. Reinstall the entire shell with the billet grille in place.
7. Note: These are temporary instructions, if you have any questions please feel free to call Carriage Works at 816-966-1405 for technical help.