



41361 / 41362 / 41363 1998-2002 Camaro Installation Instructions

For installation of billet grilles that require cutting of the stock shell, proper tools, knowledge and skill are needed. Carriage Works is not responsible for care & accuracy of the installation, only for Fit & Finish of its products. Use a qualified installer or contact original vendor for references to complete all instructions.

Step 1 – Remove center black plastic insert by bending it upwards from the bottom, cut the bottom plastic attachment studs. By bending it further upward you are able to cut the upper attachment studs. Remove plastic center section.

Step 2 – Mask center opening off and paint with flat or semi gloss black paint.

Step 3 – Insert billet grille into opening, mark and drill the four (4) attachment holes with a 1/8" drill bit.

Step 4 – Reinsert billet grille and secure the four Phillips head screws provided.

Rev.05/01/01



41361 / 41362 / 41363 1998-2001 Camaro Installation Instructions

For installation of billet grilles that require cutting of the stock shell, proper tools, knowledge and skill are needed. Carriage Works is not responsible for care & accuracy of the installation, only for Fit & Finish of its products. Use a qualified installer or contact original vendor for references to complete all instructions.

Step 1 – Remove center black plastic insert by bending it upwards from the bottom, cut the bottom plastic attachment studs. By bending it further upward you are able to cut the upper attachment studs. Remove plastic center section.

Step 2 – Mask center opening off and paint with flat or semi gloss black paint.

Step 3 – Insert billet grille into opening, mark and drill the four (4) attachment holes with a 1/8" drill bit.

Step 4 – Reinsert billet grille and secure the four Phillips head screws provided.

Rev.05/01/01