



2006 Nissan Altma (1-piece bumper grille)

Part# 42761 (Brushed) 42762 (Polished) 42763 (Black)

After



HARDWARE

- 2 - Brackets
- 2 - U-Clips
- 2 - #8 x 5/8" Phil Pan head Screws



1 Remove the (5) 10mm bolts from under splash guard, located under front end of vehicle.



2 Place U-Clips on Brackets as shown above.



3 Loosely attach the brackets to the billet grille as shown above using the supplied #8 x 5/8" Phil pan head screws.



4 Place billet grille into opening and center. Reaching up thru from the bottom "splash guard area", rotate the brackets around so that they catch the middle plastic in stock bumper opening.



5 Tighten up without over tightening.

For installation of billet grilles that require cutting of the stock shell, proper tools, knowledge and skill are needed. Carriage Works is not responsible for care & accuracy of the installation, only for Fit & Finish of its products. Use a qualified installer or contact original vendor for references to complete all instructions.

NOTE: Please adjust horizontal blades if irregular. This is the result of shipping and handling outside of Carriage Work's control. Also Carriage Works Inc. Recommends applying a high quality automotive wax to maintain the original appearance.