



# 2006 Mustang V6 (Pony Package Bolt Over)

**PART# 42921(Brushed) - 42922(Polished) - 42923(Black)**

## Hardware

- 4 - 1/4-20 x 1 1/2" Bolts
- 4 - 1/4-20 x 1" Bolts
- 8 - 1/4-20 Nyloc nuts
- 2 - Brackets "Straps"



Place the billet grilles into the correct openings (top & bottom) and center. Using a scribe mark the hole locations for the (2) outer mounting tabs in billet grille as shown. Then repeat for the other side.



Remove the billet grilles from opening. Using a 9/32" drill bit, drill in the just marked hole locations as shown.



Place billet grilles back into opening & center. Place the supplied 1/4-20 x 1" in the just drilled locations. Attach using the supplied 1/4-20 Nyloc nuts.



Place the supplied 1/4-20 x 1 1/2" bolts into mounting tabs located by the (Ford Mustang "Pony" emblem). Reaching behind the shell place the flat strapping bracket onto bolts and attach using 1/4-20 Nyloc nuts.

For installation of billet grilles that require cutting of the stock shell, proper tools, knowledge and skill are needed. Carriage Works is not responsible for care & accuracy of the installation, only for Fit & Finish of its products. Use a qualified installer or contact original vendor for references to complete all instructions.

NOTE: Please adjust horizontal blades if irregular. This is the result of shipping and handling outside of Carriage Works control. Also Carriage Works Recommends applying a high quality automotive wax to maintain the original appearance.