



2007 GMC Yukon (Bolt Over)

After

PART# 43101(Brushed) - 43102(Polished) - 43103(Black)

Hardware

Photo shown with optional Full Bumper grille Part#4312



Before

4 - Toggle Bolt Assembly



Place toggle bolts thru mounting tabs in billet grille as shown above.



Place billet grille into opening and center. Then push the toggle bolts thru as shown above.



Simply tighten up the toggle bolts. To help start bolts it maybe necessary to pull out on the billet grille so that there is something for the bolt to tighten against. Another method is to use a second screwdriver to help hold the wing nut until it snugs up against the shell.

Completed Installation

For installation of billet grilles that require cutting of the stock shell, proper tools, knowledge and skill are needed. Carriage Works is not responsible for care & accuracy of the installation, only for Fit & Finish of its products. Use a qualified installer or contact original vendor for references to complete all instructions.

NOTE: Please adjust horizontal blades if irregular. This is the result of shipping and handling outside of Carriage Works control. Also Carriage Works Recommends applying a high quality automotive wax to maintain the original appearance.