



2006 Dodge Charger SRT8 Bumper Grille

After

PART# 43211(Brushed) - 43212(Polished) - 43213(Black)



- 2 - Square Tabs
- 2 - 10/32 x 2" Phillips head bolts
- 2 - 10/32 Nyloc safety nuts



1
Remove the (7) 7mm bolts from under front end that hold plastic air shroud in place. Also remove the (8) plastic push pull rivets by pulling out on the inner portion of the rivet to release. Plastic shroud will be free at this point.



2
Place billet grille into opening and center. Place the 10/32 x 2" Phillips head bolts into the mounting tabs in billet grille. Then reaching up from under the front of the vehicle place a supplied square tab on the backside of the honeycomb onto the just place 10/32 x 2" bolts and attach with 10/32" Nyloc safety nuts.

Photo shown W/optional bumper grille



Completed Installation

For installation of billet grilles that require cutting of the stock shell, proper tools, knowledge and skill are needed. Carriage Works is not responsible for care & accuracy of the installation, only for Fit & Finish of its products. Use a qualified installer or contact original vendor for references to complete all instructions.

NOTE: Please adjust horizontal blades if irregular. This is the result of shipping and handling outside of Carriage Works control. Also Carriage Works Recommends applying a high quality automotive wax to maintain the original appearance.