



# 2007 Chevy Tahoe Invisi-Lok™ Tow hook Bumper Grille (2pc)

After



Part# 43771 (Brushed) 43772 (Polished) 43773 (Black)  
Invisi-Lok™ Tow hook Bumper Grille

## HARDWARE

- 6 - 10-32 x 5/8" Bolts
- 6 - 10-32 Nyloc nuts



Remove the rubber surrounding tow hooks, by pushing straight back to release.



Place billet grille into opening and center. Then using a 90° scribe mark the location of the mounting holes in billet grille where it meets the vehicle as shown.



Remove the billet grille from opening. Now drill just marked location using a 3/16" drill bit.



Mount the billet grilles using the supplied 10-32 x 5/8" stainless steel bolts and 10-32 nyloc nuts. Needle nose pliers also will aid in the placement of the bolts.

Completed Installation

For installation of billet grilles that require cutting of the stock shell, proper tools, knowledge and skill are needed. Carriage Works is not responsible for care & accuracy of the installation, only for Fit & Finish of its products. Use a qualified installer or contact original vendor for references to complete all instructions.

NOTE: Please adjust horizontal blades if irregular. This is the result of shipping and handling outside of Carriage Work's control. Also Carriage Works Inc. Recommends applying a high quality automotive wax to maintain the original appearance.