




# 2008 Nissan Armada

PART# 44181 (Brushed) 44182 - (Polished) 44183 - (Black)



## Hardware

- 8 - Brackets 
- 8 - 10-24 x 2" phillips head bolts
- 8 - 10-24 Nyloc nuts



1 Start by locating the supplied brackets and 10-24" nyloc nuts. To make the installation of the brackets easier, tape the nut on the backside of the bracket as shown. You can remove the tape after you get the bolt started.



2 Place billet grille into opening and center. Place supplied 10-24 x 2" bolts thru mounting tabs in billet grille. Attach brackets on the backside of the stock shell without over tightening.

## Completed Installation

For installation of billet grilles that require cutting of the stock shell, proper tools, knowledge and skill are needed. Carriage Works is not responsible for care & accuracy of the installation, only for Fit & Finish of its products. Use a qualified installer or contact original vendor for references to complete all instructions.

NOTE: Please adjust horizontal blades if irregular. This is the result of shipping and handling outside of Carriage Works control. Also Carriage Works Recommends applying a high quality automotive wax to maintain the original appearance.