



2008 Toyota Sequoia

Bolt Over Upper

After




PART# 44311 (Brushed) 44312 - (Polished) 44313 - (Black) Upper

Before



Hardware

- 11 - Brackets 
- 11 - 10-24 x 1" Phillips head bolts
- 11 - 10-24 U-clips



1 Start by placing the supplied 10-24 U-clips on the mounting hole of the supplied brackets. Now place one of the supplied 10-24 x 1" phillips head bolts through the mounting tabs in billet grille as shown above and thread into the u-clip until it's flush with backside of the u-clip. Repeat process for remaining brackets until all brackets are attached to the remaining billet grilles.



2 You can choose as to which billet grille you start with. We placed the bottom billet grille into opening and centered. Note that the bottom billet grille is longer than the top and also has 3 mounting holes and the upper has 4. Now check for alignment and tighten up the brackets starting in the middle and working out.



3 Repeat process for remaining billet grilles.

Completed Installation

For installation of billet grilles that require cutting of the stock shell, proper tools, knowledge and skill are needed. Carriage Works is not responsible for care & accuracy of the installation, only for Fit & Finish of its products. Use a qualified installer or contact original vendor for references to complete all instructions.

NOTE: Please adjust horizontal blades if irregular. This is the result of shipping and handling outside of Carriage Works control. Also Carriage Works Recommends applying a high quality automotive wax to maintain the original appearance.