



# 2015 Chevy HD 2500-3500

## Bumper Grille

PART# 47401 (Brushed) 47402 - (Polished) 47403 - (Black) Upper



### Hardware

- 2 - Brackets #-4438
- 2 - 10-24 x 1" bolts
- 2 - 10-24 U-Clips
- 2 - 1/4-20 x 1" Bolts
- 2 - 1/4-20 Lock Nut
- 2 - 1/4" Flat Washer



1  
Locate the supplied brackets shown above then place supplied u-clip on the short end of both brackets.



2  
Next locate and remove the stock 10mm bolts located on each side of the bumper opening. Next attach brackets using the just removed 10mm bolts as shown above.



3  
Next place billet grille into bumper opening and center. Attach billet grille to the already placed brackets using the supplied 10-24 x 1" bolts.

**NOTE: If you vehicle does not have the 10mm bolts, use the 1/4-20 x 1" bolts, washers & lock nuts provided.**