



CW GRILLES

A DIVISION OF
CW LASER AND FABRICATION

Installation Guide

Part # 4026

(-1, Brushed; -2, Polished; -3, Black)

This model fits:

Thank you for purchasing the CW Grilles **4026.**

1994-99 GMC Full Size & Yukon

For installation of billet grilles that require cutting of the stock shell, proper tools, knowledge and skill are needed. CW is not responsible for care & accuracy of the installation, only for Fit & Finish of its products. Use a qualified installer or contact original vendor for references to complete all instructions.

Hardware Included

- (1) #6 X 1/2 SELF TAPPING SCREW
- (5) 1/8 X 3/8 POP RIVET

Brackets Included

- (1) B-4026-1 BRACKET



STEP 1 Remove parking lights, then the grille shell.



STEP 2 With a cutoff wheel or saber saw, cut out the egg-crate insert from the original grille.



STEP 3 Grind the insert attachment points down smooth.



STEP 4 Sand the shell opening smooth and touch up the paint.



STEP 5 Set the grille in place in the opening and mark around the vertical posts where they contact the frame.



STEP 6 Drill 5/64" holes where marked.



STEP 7 Reinstall the grille and pop rivet the posts in at five locations, three on top and two on bottom.



STEP 8 Secure the center post on the bottom with the bracket provided.

