



Installation Guide

Part # 4077

(-1, Brushed; -2, Polished; -3, Black)

This model fits:

1957 Chevy Passenger Car Phantom

Thank you for purchasing the CW Grilles **4077**.

For installation of billet grilles that require cutting of the stock shell, proper tools, knowledge and skill are needed. CW is not responsible for care & accuracy of the installation, only for Fit & Finish of its products. Use a qualified installer or contact original vendor for references to complete all instructions.

Hardware Included

- (8) 1/4-20 NYLOC NUTS
- (8) 1/4-20 X 3/4 SOCKET HEAD

Brackets Included

NOTE: Stock turn signals and light bar are removed. Aftermarket turn signals must be used for this grille.

STEP 1 Remove bumper, light bar and stock grille.

STEP 2 Remove center vertical support.

STEP 3 Center vertical support bar has a section which sticks out forward that the light bar is attached to. This section must be cut off of support. Cut where the front nose is cut off making front all the same line.

STEP 4 Replace center vertical support.

STEP 5 Now your ready to install Billet grille, by inserting top first. Top tabs should mount in factory mounting holes.

STEP 6 Install bolts in top tabs and leave loose. Now mark the location of bottom tabs onto splash apron. It may be necessary to put bumper back on car to get proper spacing for bottom tabs. This is recommended for the best fitment.

STEP 7 Remove bumper and billet grille. Drill 1/4" hole at the marked location of bottom tabs.

STEP 8 Install grille and bumper. Aftermarket turn signal lights will need to be relocated behind grille.

