



# Installation Guide

## Part # 4136

(-1, Brushed; -2, Polished; -3, Black)

This model fits:

**1998-2002 Chevy Camaro**

Thank you for purchasing the CW Grilles **4136.**

For installation of billet grilles that require cutting of the stock shell, proper tools, knowledge and skill are needed. CW is not responsible for care & accuracy of the installation, only for Fit & Finish of its products. Use a qualified installer or contact original vendor for references to complete all instructions.

### Hardware Included

(4) 10-24 X 1 1/4 PHILLIPS BOLTS

### Brackets Included

**STEP 1** Remove center black plastic insert by bending it upwards from the bottom, cut the bottom plastic attachment studs.

**STEP 2** Bend it further upward so you are able to cut the upper attachment studs, too. Remove plastic center section.

**STEP 3** Tap center opening off and paint with flat or semi gloss black paint.

**STEP 4** Insert billet grille into opening, mark and drill the four (4) attachment holes with a 1/8" drill bit.

**STEP 5** Reinsert billet grille and secure the four Phillips head screws provided.

