



Installation Guide

Part # 4099

(-1, Brushed; -2, Polished; -3, Black)

This model fits:

1967-68 Chevy Camaro Passenger Car

Thank you for purchasing the CW Grilles **4099**.

For installation of billet grilles that require cutting of the stock shell, proper tools, knowledge and skill are needed. CW is not responsible for care & accuracy of the installation, only for Fit & Finish of its products. Use a qualified installer or contact original vendor for references to complete all instructions.

Hardware Included

(8) #6 X 1/2 SELF TAPPING SCREWS

Brackets Included

STEP 1 Tape off all chrome or painted surfaces to prevent damage.

STEP 2 Using a cut-off wheel, cut out vertical and horizontal bars of stock grille.

STEP 3 Using a sander or sanding block sand all rough edges smooth. Repaint if necessary.

STEP 4 Center Billet grille into opening, and mark vertical rod locations.

STEP 5 Drill 1/8" holes at each marked location.

STEP 6 Attach grille by using supplied screws.